



SM, SD/Mini SD, MMC/RSMMC,  
MS/MS-Pro/MS-Duo

Nöt  
TV  
Only

CF

NOT ONLY TV  
Digimedia Player  
Enjoy photos, music and movies on your TV or Monitor!

NOT ONLY TV



# NOT ONLY TV



Enjoy photos, music and movies on your TV or Monitor!

## Digimedia Player



NOT ONLY TV  
Digimedia Player

- Plug and play hardware solution – **no need for a PC**
- View your digital **photos** on a TV or monitor
- Playback **MP3** and **WMA**
- Supports **JPG, JPEG, BMP, PNG, GIF** **album preview**, rotate and zoom
- Video format: **MPEG 1/2/4, Divx, AVI, MP4, MPG, VOB, DAT**
- Enjoy **slideshow**s with music background (MP3)
- Supports **SM, SD/Mini SD, MMC/RSMCC, MS/MS-Pro/MS-Duo, CF**



- Plug and play hardware solution - no need for a PC
- Plug and play Hardware-Lösung - Es wird kein PC benötigt
- Soluzione hardware plug and play - nessun bisogno di PC
- Compatible avec Plug & Play - Pas besoin d'un PC
- Hardware Plug and Play - ¡no hace falta un PC
- Solução Plug and Play ao nível do hardware - não é necessário um PC



- View your digital photos on a TV or monitor
- Genießen Sie Ihre digitalen Fotos auf Ihrem Fernseher oder Monitor
- Visualizza le foto digitali su TV o monitor
- Affichez vos photos numériques sur votre télévision ou un monitor
- Visualice sus fotografías digitales en su TV o monitor
- Visualização de fotos digitais num televisor ou monitor



- Playback MP3 and WMA
- Wiedergabe von MP3 und WMA
- Riproduce MP3 e WMA
- Utilisez des fichiers MP3 et WMA
- Reproduzca archivos MP3 y WMA
- Reprodução de ficheiros MP3 e WMA



- Supports JPG, JPEG, BMP, PNG, GIF album preview, rotate and zoom
- Unterstützt JPG, JPEG, BMP, PNG, GIF Album-Voranzeige, drehen und Zoomen
- Supporta anteprime album JPG, JPEG, BMP, PNG, GIF, rotazioni, zoom
- Supporte la prévisualisation des albums JPG, JPEG, BMP, PNG, GIF, la rotation et les zooms
- Soporta previsualización, girar y zoom de álbumes JPG, JPEG, BMP, PNG, GIF
- Suporte para o formato JPG, JPEG, BMP, PNG, GIF para pré-visualização do álbum fotográfico e para as funções de rotação e de zoom



- Video format: MPEG 1/2/4, Divx, AVI, MP4, MPG, VOB, DAT
- MPEG 1/2/4, Divx, AVI, MP4, MPG, VOB, DAT Video Dateien
- Riproduce file video MPEG 1/2/4, Divx, AVI, MP4, MPG, VOB, DAT
- Utilisez des fichiers vidéo MPEG 1/2/4, Divx, AVI, MP4, MPG, VOB, DAT
- Reproduzca vídeo MPEG 1/2/4, Divx, AVI, MP4, MPG, VOB, DAT
- Reprodução de ficheiros de vídeo MPEG 1/2/4, Divx, AVI, MP4, MPG, VOB, DAT



- Enjoy slideshows with music background (MP3)
- Erstellen Sie Diaschows mit Hintergrundmusik (MP3)
- Consente presentazioni con musica di sottofondo (MP3)
- Regardez un diaporama avec de la musique de fond (MP3)
- Realice proyecciones con música de fondo (MP3)
- Desfrute dos diapositivos com música de fundo (MP3)




- Supports SM, SD/Mini SD, MMC/RSMMC, MS/MS-Pro/MS-Duo, CF
- Unterstützt SM, SD/Mini SD, MMC/RSMMC, MS/MS-Pro/MS-Duo, CF
- Supporta schede SM, SD/Mini SD, MMC/RSMMC, MS/MS-Pro/MS-Duo, CF
- Fonctionne avec des cartes mémoires SM, SD/Mini SD, MMC/RSMMC, MS/MS-Pro/MS-Duo, CF
- Soporta SM, SD/Mini SD, MMC/RSMMC, MS/MS-Pro/MS-Duo, CF
- Suporte para cartões de memória SM, SD/Mini SD, MMC/RSMMC, MS/MS-Pro/MS-Duo, CF

## Package Contents

- Digimedia player
- Composite Video and audio cable
- S-Video cable
- Infrared remote control
- Power adaptor
- User guide

<b>Interface</b>		Compact Flash Type I/II Smart media, MS, MS-pro, MS-Duo, SD, Mini SD, MMC, RSMMC
<b>Output</b>	<b>Video</b>	• Composite video (RCA jack) • S-Video (mini-Din 4 pin)
	<b>VGA</b>	D-Sub 15 pin (Female)
	<b>Audio</b>	3.5 headphone jack
<b>Pixel Size</b>		Photo - Up to 19M pixels (5120x3840) Video - 640x480 Pixels
<b>File Format</b>		VIDEO: MPEG 1/2/4 AUDIO: MP3 PHOTO: JPEG
<b>IR</b>		Infrared Remote Control
<b>Power Supply</b>		AC Adapter +5V DC ( inner "+", outer "-" ) Power jack
<b>Dimension</b>		13.5x9.0x3.4cm



# NOT TV Only



## NOT ONLY TV Digimedia Player

*Enjoy photos, music and movies on your TV or Monitor!*

Enjoy **photos**, **music** and **movies** on your TV with the Digimedia player that is an affordable easy to use digital photo player which makes you enjoy an instant *slideshow* of your pictures also with music playing in the background.

With its great features, you can easily watch high quality videos (MPEG 1/2/4), listen to digital music files (**MP3**) and watch a slideshow of your pictures.

All you need to do is only to connect the device with your big TV screen or LCD monitor and share your magic moments with your friends.

The Digimedia player supports up to **10 different kinds of storage** :  
CF Type I/II, Smart media, MS, MS Duo and MS pro, SD and mini SD, MMC, RSMMC.



[www.lifeview.hk](http://www.lifeview.hk)